

Contents

AR-321L485-5V: TTL to RS485 Converter

1 Product




Features

- TTL to RS485 converter (TTL and RS485 cable is detachable)
- Suitable for E/H-V5 Series Controller when connected to Lift Control Panel AR-401-IO-0016R (16 output NC/NO changeable; default value: NC)
- Power Supply 5VDC (Powered by Controller)

Connector Table

Cable : **CN2**

Wire Application	Pin	Color	Description
Communication	1	Thick Blue	RS-485+
Interface RS485	2	Thick Green	RS-485-



Cable : **CN3**

Wire Application	Pin	Color	Description
Power	1	Black	Power DC 0V
	2	Yellow	TX
TTL Port	3	White	RTS(Request to Send)
	4	Orange	RX
Power	5	Red	Power DC 5V

Wiring Diagram

BAUD9600 / N.C. Type
EX : Node 001



AR-401-IO-0016R

5VDC power is powered by controller, does not require additional power supply

Connect TTL cable to CN11

